

FR SKATES SIZE CHARTS

SL SPEED / SL SPEED 195


To find your correct size, first refer to your current shoe size. For a more accurate measurement, use this method: Place a sheet of paper against a wall on a hard-surfaced floor. Place your heel against the wall and outline your feet one at a time. Measure the distance from heel to toe in centimeters. Use the longest measurement to match your best fit on the size chart below. The table considers the original liner size, without any additional footbed.



SL SPEED Skates are equipped with integrated Intuition heat-moldable liners, for an optimized fit.

To mold the liners, refer to the molding instructions following below link. Before molding, try both skates on with any footbeds/orthotics you intend to use, to ensure they fit your feet properly.

Not too tight, not too sloppy! **Do not mold if the skates don't fit!**https://intuitionliners.com/wp-content/uploads/2019/09/IntuitionHomeFit.pdf



CHECK FOR PROPER FIT When trying on the skates the toes shouldn't be pressed against the front of the skate and should lay flat. Toes can touch slightly the front of the skates, without pressure point.

FR SKATES				
Model SL SPEED / SL SPEED 195				
Measured Foot (cm)	Suggested Size EU	Suggested Size US	Suggested Size UK	Suggested Size MP
22	34	3	2	22
22.5	35	4	3	22.5
23	36	4.5	3.5	23
23.5	37	5	4	23.5
24.5	38	6	5	24.5
25	39	7	6	25.5
25.5	40	7.5	6.5	26
26	41	8	7	26.5
27	42	9	8	27
28	43	10	9	27.5
29	44	10.5	9.5	28
29.5	45	11	10	28.5
30	46	12	11	29.5
30.5	47	13	12	30